



TUTTE LE OPERAZIONI DEVONO ESSERE EFFETTUATE DA PERSONALE SPECIALIZZATO


ALL OPERATIONS MUST BE CARRIED OUT BY QUALIFIED PERSON - TOUS LES OPERATIONS DOIVENT ETRE EFFECTUEES PAR DES PROFESSIONELLES



1.  
Fix the adaptor plate provided to the J-BOX.  
Then fix the base of the lamp to the plate fixed just now.




2.  
Insert the cable of the SOLITARIO SO in the cable-lock cylinder as shown in the image.



3.  
Connect the lamp to the main power following the sketch.  
Make sure that the canopy's cylinder is screwed all the way on its support



TUTTE LE OPERAZIONI DEVONO ESSERE EFFETTUATE DA PERSONALE SPECIALIZZATO

ALL OPERATIONS MUST BE CARRIED OUT BY QUALIFIED PERSON - TOUS LES OPERATIONS DOIVENT ETRE EFFECTUEES PAR DES PROFESSIONELLES



4.  
Fix the canopy to the bracket  
using the three screws provided

5.  
Apply the desired sphere  
"Smoke", "Flood" or "Spot"  
120 or 200 mm diameter  
or the lens "Flood" or "Spot"  
using the provided screws



3 holes canopy

5 holes canopy

Repeat steps 2, 3 and 4  
for 3 and 5 holes canopy.